



Guest / Side / Stacking Chair Disassembly



1 Chair Series: ADVENT, COBRA, EDU, EDU², MONTEREY II, PEARL II
Tools Required: Phillips & Flat Head Screwdrivers, Needle Nose Pliers, Staple Puller, Hammer

2 The outer back is attached to the back rest with either nails or 6 plastic, push-in fasteners. Remove the outer back by sliding the flat head screwdriver into the gap between the outer back and the back rest. Gently pry the outer back away from the back rest moving all around the back until the outer back falls away. Using the needle nose pliers, remove any nails.



ADVENT's plastic outer back is attached with 4 plastic, push-in fasteners.



3 The back rest is mounted to the frame with 4 screws. Using the phillips head screwdriver, remove the 4 Screws.



4 Arm Chairs: 2 plastic arms are press fitted into the steel frame. Using the hammer, strike the underside of the plastic arm away from the steel frame and knock away the 4 plastic ball glides from the bottom of a 4-leg steel frame.





5 Armless Chairs: 4 plastic plugs are press fitted into the steel frame. Using the flat head screwdriver, pry the plastic plug out of the steel frame. Using the hammer, knock away the 4 plastic ball glides from the bottom of a 4-leg steel frame.



We strive to use North American (non-imported) components in our manufacturing process Proudly Manufactured in Western New York!



CHAIRS THAT FIT EVERY TASK - FOR EVERY BODY		"BUILT IN AMERICA WITH QUALITY NORTH AMERICAN MADE COMPONENT PARTS" SEATING SERIES 275 STANDARD FIT 350 INTENSIVE USE & HEAVY DUTY 550 GENEROUS FIT	
PO Box 898 60 N. State Street Nunda, New York 14517 800.46 8.247 5 F 585.468.2804 sales@seatinginc.com www.seatinginc.com			

Guest / Side / Stacking Chair Disassembly



- 6 The seat is mounted to the steel frame with 4 screws.
Turn the chair over. Using the phillips head screwdriver, remove the 4 screws.



- 7 The upholstery is stapled to the wood substructures. Using the staple puller, remove the staples.



- 8 The upholstery is glued to the foam cushions. The foam cushions are glued to the wood substructures. Pull the upholstery away from the foam cushions. Pull the foam cushions away from the wood substructures while using the flat head screwdriver or the staple puller to assist the release.



- | | |
|-----------------------|---|
| 9 Parts List: | Composition: |
| 8 Screws |  Steel |
| Staples |  Steel |
| 2-3 Substructures | Wood |
| 3-4 Upholstery Pieces | Fabric, Vinyl, or Leather |
| 2 Cushions | Foam |
| 1 Frame |  Steel |
| If Applicable: | |
| 1 Outer Back | Plastic |
| 4-6 Push-in Fasteners | Plastic |
| Nails |  Steel |
| 2 Arms | Plastic |
| 4 Plugs | Plastic |
| 4 Ball Glides | Plastic |

We strive to use North American (non-imported) components in our manufacturing process
Proudly Manufactured in Western New York!

